

STA00840

WAIST TRIMMER BELT OWNER'S MANUAL



DICK'S Sporting Goods 345 Court Street Coraopolis, PA 15108

***FITNESS
GEAR***



TABLE OF CONTENTS

SECTION	PAGE
BEFORE YOU BEGIN	1
IMPORTANT SAFETY NOTICE	2
IMPORTANT CARE AND MAINTENANCE	2
IMPORTANT OPERATIONAL INSTRUCTIONS	2
LIMITED WARRANTY	3

BEFORE YOU BEGIN

Thank you for selecting the Fitness Gear WAIST TRIMMER BELT. For your safety and benefit, read this manual carefully before using the waist trimmer belt. If you have any questions, or find there are missing or damaged parts, please contact our Customer Service Agents.

Toll-Free Customer Service Number
1-877-846-9997
Mon. – Fri. 9 a.m. – 5 p.m. EST

RETAIN THESE INSTRUCTIONS FOR FUTURE USE



IMPORTANT ! SAFETY NOTICE

For your safety and benefit, read the following instructions carefully prior to assembly or use. Failure to follow all instructions and safety precautions can result in **serious injury or death or damage to equipment.**

WARNING

1. CONSULT WITH YOUR PHYSICIAN BEFORE BEGINNING ANY EXERCISE PROGRAM.
2. Intended for use during short periods of time. Overuse can lead to overheating, heat exhaustion and dehydration.
3. Do not use in a sauna. Not for use in hot temperatures or during extreme conditioning. If you become dizzy or light headed, immediately discontinue use and consult a physician.
4. Not intended to be used as a tourniquet. Use only on waist – not intended for use on other body parts. Do not use waist trimmer over broken skin.
5. This exercise equipment is **NOT FOR USE BY CHILDREN UNDER AGE 14.**
6. This product contains neoprene that may cause an allergic reaction. If any irritation occurs, discontinue use and consult a medical professional.



IMPORTANT! CARE AND MAINTENANCE

1. Inspect all parts before using the product for signs of wear or failure. If parts are worn or damaged, DO NOT use. Contact Customer Service for replacement parts.
2. Exercise caution when adjusting tightness of belt as over-tightening can lead to shortness of breath. For more comfortable use, make sure that hook and loop does not touch bare skin.
3. To clean: Gently hand wash in cool water with mild detergent. Drip dry. DO NOT tumble dry. DO NOT iron.



IMPORTANT! OPERATIONAL INSTRUCTIONS

This product is designed to be used for training, exercise, and physical fitness activities only.

This product is designed and intended for residential and consumer use only, not for commercial use.

WARNING

CONSULT WITH YOUR DOCTOR BEFORE BEGINNING ANY EXERCISE PROGRAM. READ ALL INSTRUCTIONS BEFORE USING ANY FITNESS EQUIPMENT. NOT FOR USE BY CHILDREN UNDER AGE 14. INSPECT FOR DAMAGE BEFORE EACH USE.

SAVE THESE INSTRUCTIONS

LIMITED WARRANTY

Dick's Sporting Goods, Inc. (the "Company") warrants this product to be free from defects in workmanship and materials as follows:

Who is Covered

This Limited Warranty covers only the person who first bought the product. This Limited Warranty is not transferable to anyone else.

What the Warranty Covers

This Limited Warranty covers defects in materials and workmanship.

What the Warranty Does Not Cover

This Limited Warranty does not cover:

- Expendable items, including by way of example only and not by way of limitation: batteries, light bulbs, fuses, zippers, tires, belts, shoe soles, fabric, and other items that experience wear as a result of normal use.
- Damage through improper use, negligence, abuse, misuse, transportation, acts of nature, or accident, including failure to perform routine maintenance or follow the assembly and/or operating instructions supplied with the product.
- Products used in commercial or rental applications.
- Products that have been modified or repaired by anyone not authorized by the Company.

This Limited Warranty does not cover any consequential or incidental damages of any kind, including transportation to get warranty service, loss of time, and loss of use. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

What the Period of Coverage Is

This Limited Warranty lasts for a period of one year from the date of your original purchase. Any implied warranty arising under state law is limited in duration to the one-year period of this Limited Warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

What the Company Will Do to Correct Problems

The Company will furnish a replacement part at no charge to you.

How You Can Get Service

Please direct all warranty service inquiries as follows:

If in writing, mail to:

**Dick's Sporting Goods, Inc.
345 Court St.
Coraopolis, PA 15108
Attn: Customer Service**

If by telephone, call: **1-877-846-9997**

How State Law Applies

This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.