



Nut Buddy Tool Set



## Instructions for Nut/Bolt Disassembly

**Step 1:** Fix the suitable **socket** to the front square drive on the **58:1 Assembly** and affix the **handle** to the square drive on the back of the **58:1 Assembly**.



**Step 2:** Fix the **socket** over the nut/bolt and loosen the nut/bolt one or two rotations until it moves freely. Do not exceed more the 45lbs/25kg of force or damage to the threads, bolt, or nut may result.

**Step 3:** Use the socket and handle with the **1:1 Connection Rod** to remove the loosened nut or bolt.



## Nut Buddy Components



58:1 Assembly

Handle

## Sockets

1-5/16" (33mm) & 1-1/2" (38MM)



## 1:1 Connection Rod

